



Alterar IP de LAN

**DIR-905L**

# DIR-905L



## Procedimentos para alterar o endereço IP de LAN do roteador


- 1- Para alterar o IP de LAN o computador deve estar conectado via cabo Ethernet em uma das portas LAN do DIR-905L e o seu Modem ADSL conectado na porta Internet do DIR-905L.



2- Para acessar a página de configuração abra o Internet Explorer, digite na barra de endereços <http://192.168.0.1> e tecla **Enter**.



No centro da tela abrirá os campos para autenticação.



O usuário e senha padrão do equipamento é:

**User Name:** admin

**Password:** (deixe em branco)

Clique apenas em **Log In**.

### 3- Clique em **Setup Manual**.

**CURRENT NETWORK SETTING**

The current network settings and the connection status are displayed below. If you want to reconfigure your wireless settings, please click the "Configure" button. You can also enter advanced settings by clicking "Manual Setup".

**Internet Settings**

Internet Connection : PPPoE      Status : **Connected**

**Wireless Settings**

Network Name (SSID) : DIR-905L      Status : **Encryption**      [Configure](#)

Security : Auto (WPA or WPA2) - Personal

Network Key : MydlinkMydlink

**Device Info**

User Name : admin

Password : Mydlink

**mydlink Account**

You have not activated mydlink service.      Status : **Not Connected**      [Configure](#)

Save my network settings

[Cancel](#) [Manual Setup](#) [Save](#)

3- Clique nas abas **Setup > Lan Setup** e altere os seguintes parâmetros:

**Router IP Address:** digite o novo endereço IP do roteador

**Subnet Mask:** digite a máscara de sub-rede

**Local Domain Name: (opcional)**

Habilite a opção **Enable DNS Relay**

Clique em **Save Settings** e em seguida clique em **Reboot Now**.

Product Page : DIR-905L Hardware Version : Ax Firmware Version : 1.00

**D-Link**

DIR-905L // **SETUP** ADVANCED MAINTENANCE STATUS HELP

Easy Setup  
Internet Connection  
Wireless Connection  
**Lan Setup**  
Time and Date  
Parental Control Rules  
Logout

**LAN SETUP**

Use this section to configure the internal network settings of your router and also to configure the built-in DHCP Server to assign IP addresses to the computers on your network. The IP Address that is configured here is the IP Address that you use to access the Web-based management interface. If you change the IP Address here, you may need to adjust your PC's network settings to access the network again.

**Please note that this section is optional and you do not need to change any of the settings here to get your network up and running.**

Save Settings Don't Save Settings

**ROUTER SETTINGS**

Use this section to configure the internal network settings of your router. The IP Address that is configured here is the IP Address that you use to access the Web-based management interface. If you change the IP Address here, you may need to adjust your PC's network settings to access the network again.

Router IP Address: 192.168.1.1  
Subnet Mask : 255.255.255.0  
Local Domain Name :  
Enable DNS Relay :

Helpful Hints...  
If you already have a DHCP server on your network or are using static IP addresses on all the devices on your network, uncheck **Enable DHCP Server** to disable this feature.  
If you have devices on your network that should always have fixed IP addresses, add a **DHCP Reservation** for each such device.  
More...

Product Page : DIR-905L Hardware Version : Ax Firmware Version : 1.00

**D-Link**

DIR-905L // **SETUP** ADVANCED MAINTENANCE STATUS HELP

Easy Setup  
Internet Connection  
Wireless Connection  
Lan Setup  
Time and Date

**REBOOT NEEDED**

Your changes have been saved. The router must be rebooted for the changes to take effect. You can reboot now, or you can continue to make other changes and reboot later.

Reboot Now Reboot Later

Helpful Hints...  
Enable Auto Channel Scan so that the router can select the best possible channel for your wireless network to operate on.

